

What is a deviating sample?

A deviating sample has not been correctly cared for, or the information received is not sufficient in order to ascertain if it has been correctly cared for. Examples are:

- No date sampled samples deviate automatically
- Received in the incorrect container for the testing required
- Received outside of the recommended holding time
- Sample contains significant headspace

All of these factors may affect the quality of the sample and therefore in turn the quality of the analytical data produced. The analysis completed maintains its accreditation; however the results may be considered to be deviating and should be interpreted with caution.

At i2 Analytical we have worked hard to establish sample receipt and preservation methods which cause minimal fuss to our customers.

Soil Samples

For chemical analysis, soil samples should be preserved by cooling, using frozen ice packs in the cool boxes or enviro sample kits. The sample environment should be kept below 12 °C where possible <u>or</u> received in the lab within 24 hours of sampling with frozen ice packs.

Samples should then be received (with testing instruction) at the main sample reception in Watford within the recommended time frame, for standard soil analysis this is within 7 days of sampling.

Soil Vial

PTFE liner VOC analysis TPH< C10



Soil Jar Standard chemical testing, including organics

Water Samples

Water samples should be preserved by cooling, using frozen ice packs in the cool boxes or enviro sample kits. The sample environment should be kept below 8 °C <u>or</u> received in the lab within 24 hours of sampling with frozen ice packs.

Samples should then be received (with testing instruction) at the main sample reception in Watford within the recommended time frame. Our most time critical tests with the shortest holding times are listed below:

BOD and DO	24 hours
рН	72 hours
Ammonia	72 hours (Preserved on receipt)

Sampling/collection	Collection Method	Sample Received	Holding time OK?
Day		Day	
Thursday	Next day courier	Friday before 1pm	YES to all
Friday	i2 same day courier	Friday after 1pm	NO to BOD & DO
Friday	Next day courier	Monday am	NO to BOD & DO
Friday	Client drop off	Friday before 1pm	YES to all

Containers:

- VOC and TPH bands below C10 require a 40 ml amber glass vial, with no headspace
- Samples for BOD require a separate 300 ml amber glass bottle, with no headspace
- Samples for general chemical testing, including organics must be received in 300 ml amber glass bottles

reception@i2analytical.com
Tel: 01923 225404 Fax: 01923 237404
www.i2analytical.com

